

Nissan 300 ZX Automotive Repair Manual

by Homer Eubanks
and John H Haynes

Member of the Guild of Motoring Writers

Models covered:

Nissan 300ZX
1984 thru 1989

All models including Turbo, 2-seater and 2 + 2 with
3.0 liter V6



(8B8 - 72010)
(1137)




ABCDE
FGH


2

Haynes Publishing Group
Sparkford Nr Yeovil
Somerset BA22 7JJ England

Haynes North America, Inc
861 Lawrence Drive
Newbury Park
California 91320 USA



Turbocharged model manual transmission serial number location



Non-turbocharged model manual transmission serial number location

Manual transmission number

The 5-speed manual transmission ID number is located on a pad on the top of the bellhousing.

Automatic transmission numbers

The automatic transmission ID number is located on the right side of the housing above the oil pan.

Alternator numbers


The alternator ID number is located on top of the drive end frame.

Starter numbers

The starter ID number is stamped toward the rear of the outer case.

Battery numbers

The battery ID number is located on the cell cover segment on top of the battery.



Automatic transmission serial number location

Vehicle Emissions Control Information label

The Emissions Control Information label is attached to the hood inside the engine compartment.

Buying parts

Replacement parts are available from many sources, which generally fall into one of two categories – authorized dealer parts departments and independent retail auto parts stores. Our advice concerning these parts is as follows:

Retail auto parts stores: Good auto parts stores will stock frequently needed components which wear out relatively fast, such as clutch components, exhaust systems, brake parts, tune-up parts, etc. These stores often supply new or reconditioned parts on an exchange basis, which can save a considerable amount of money. Discount auto parts stores are often very good places to buy materials and parts needed for general vehicle maintenance such as oil, grease, filters, spark plugs, belts, touch-up paint, bulbs, etc. They also usually sell tools and general accessories, have con-

venient hours, charge lower prices and can often be found not far from home.

Authorized dealer parts department: This is the best source for parts which are unique to the vehicle and not generally available elsewhere (such as major engine parts, transmission parts, trim pieces, etc.).

Warranty information: If the vehicle is still covered under warranty, be sure that any replacement parts purchased – regardless of the source – do not invalidate the warranty!

To be sure of obtaining the correct parts, have engine and chassis numbers available and, if possible, take the old parts along for positive identification.

Maintenance techniques, tools and working facilities

Maintenance techniques

There are a number of techniques involved in maintenance and repair that will be referred to throughout this manual. Application of these techniques will enable the home mechanic to be more efficient, better organized and capable of performing the various tasks properly, which will ensure that the repair job is thorough and complete.

Fasteners

Fasteners are nuts, bolts, studs and screws used to hold two or more parts together. There are a few things to keep in mind when working with fasteners. Almost all of them use a locking device of some type, either a lockwasher, locknut, locking tab or thread adhesive. All threaded fasteners should be clean and straight, with undamaged threads and undamaged corners on the hex head where the wrench fits. Develop the habit of replacing all damaged nuts and bolts with new ones. Special locknuts with nylon or fiber inserts can only be used

once. If they are removed, they lose their locking ability and must be replaced with new ones.

Rusted nuts and bolts should be treated with a penetrating fluid to ease removal and prevent breakage. Some mechanics use turpentine in a spout-type oil can, which works quite well. After applying the rust penetrant, let it work for a few minutes before trying to loosen the nut or bolt. Badly rusted fasteners may have to be chiseled or sawed off or removed with a special nut breaker, available at tool stores.

If a bolt or stud breaks off in an assembly, it can be drilled and removed with a special tool commonly available for this purpose. Most automotive machine shops can perform this task, as well as other repair procedures, such as the repair of threaded holes that have been stripped out.

Flat washers and lockwashers, when removed from an assembly, should always be replaced exactly as removed. Replace any damaged washers with new ones. Never use a lockwasher on any soft metal surface (such as aluminum), thin sheet metal or plastic.

Fastener sizes

For a number of reasons, automobile manufacturers are making wider and wider use of metric fasteners. Therefore, it is important to be able to tell the difference between standard (sometimes called U.S. or SAE) and metric hardware, since they cannot be interchanged.


All bolts, whether standard or metric, are sized according to diameter, thread pitch and length. For example, a standard 1/2 — 13 x 1 bolt is 1/2 inch in diameter, has 13 threads per inch and is 1 inch long. An M12 — 1.75 x 25 metric bolt is 12 mm in diameter, has a thread pitch of 1.75 mm (the distance between threads) and is 25 mm long. The two bolts are nearly identical, and easily confused, but they are not interchangeable.

In addition to the differences in diameter, thread pitch and length, metric and standard bolts can also be distinguished by examining the bolt heads. To begin with, the distance across the flats on a standard bolt head is measured in inches, while the same dimension on a metric bolt is sized in millimeters (the same is true for nuts). As a result, a

standard wrench should not be used on a metric bolt and a metric wrench should not be used on a standard bolt. Also, most standard bolts have slashes radiating out from the center of the head to denote the grade or strength of the bolt, which is an indication of the amount of torque that can be applied to it. The greater the number of slashes, the greater the strength of the bolt. Grades 0 through 5 are commonly used on automobiles. Metric bolts have a property class (grade) number, rather than a slash, molded into their heads to indicate bolt strength. In this case, the higher the number, the stronger the bolt. Property class numbers 8.8, 9.8 and 10.9 are commonly used on automobiles.

Strength markings can also be used to distinguish standard hex nuts from metric hex nuts. Many standard nuts have dots stamped into one side, while metric nuts are marked with a number. The greater the number of dots, or the higher the number, the greater the strength of the nut.

Metric studs are also marked on their ends according to property class (grade). Larger studs are numbered (the same as metric bolts),



Bolt strength markings (top — standard/SAE/U.S.; bottom — metric)

Grade	Identification
Hex Nut Grade 5	 3 Dots
Hex Nut Grade 8	 6 Dots





Standard hex nut strength markings


Class	Identification
Hex Nut Property Class 9	 Arabic 9
Hex Nut Property Class 10	 Arabic 10



Metric hex nut strength markings



CLASS
10.9



CLASS
9.8



CLASS
8.8

Metric stud strength markings

while smaller studs carry a geometric code to denote grade.

It should be noted that many fasteners, especially Grades 0 through 2, have no distinguishing marks on them. When such is the case, the only way to determine whether it is standard or metric is to measure the thread pitch or compare it to a known fastener of the same size.

Standard fasteners are often referred to as SAE, as opposed to metric. However, it should be noted that SAE technically refers to a non-metric *fine thread* fastener only. Coarse thread non-metric fasteners are referred to as U.S.S. sizes.

Since fasteners of the same size (both standard and metric) may have different strength ratings, be sure to reinstall any bolts, studs or nuts removed from your vehicle in their original locations. Also, when replacing a fastener with a new one, make sure that the new one has a strength rating equal to or greater than the original.

Tightening sequences and procedures

Most threaded fasteners should be tightened to a specific torque value (torque is the twisting force applied to a threaded component such as a nut or bolt). Overtightening the fastener can weaken it and cause it to break, while undertightening can cause it to eventually come loose. Bolts, screws and studs, depending on the material they are made of and their thread diameters, have specific torque values, many of which are noted in the Specifications at the beginning of each Chapter. Be sure to follow the torque recommendations closely. For fasteners not assigned a specific torque, a general torque value chart is presented here as a guide. As was previously mentioned, the size and grade of a fastener determine the amount of torque that can safely be applied to it. The figures listed here are approximate for Grade 2 and Grade 3 fasteners. Higher grades can tolerate higher torque values.

Metric thread sizes


	Ft-lb	Nm/m
M-6	6 to 9	9 to 12
M-8	14 to 21	19 to 28
M-10	28 to 40	38 to 54
M-12	50 to 71	68 to 96
M-14	80 to 140	109 to 154

Pipe thread sizes

	Ft-lb	Nm/m
1/8	5 to 8	7 to 10
1/4	12 to 18	17 to 24
3/8	22 to 33	30 to 44
1/2	25 to 35	34 to 47


U.S. thread sizes

	Ft-lb	Nm/m
1/4 - 20	6 to 9	9 to 12
5/16 - 18	12 to 18	17 to 24
5/16 - 24	14 to 20	19 to 27
3/8 - 16	22 to 32	30 to 43
3/8 - 24	27 to 38	37 to 51
7/16 - 14	40 to 55	55 to 74
7/16 - 20	40 to 60	55 to 81
1/2 - 13	55 to 80	75 to 108



Standard (SAE and U.S.) bolt dimensions/grade marks

- G Grade marks (bolt strength)
- L Length (in inches)
- T Thread pitch (number of threads per inch)
- D Nominal diameter (in inches)



Metric bolt dimensions/grade marks

- P Property class (bolt strength)
- L Length (in millimeters)
- T Thread pitch (distance between threads in millimeters)
- D Diameter

Fasteners laid out in a pattern, such as cylinder head bolts, oil pan bolts, differential cover bolts, etc., must be loosened or tightened in sequence to avoid warping the component. This sequence will normally be shown in the appropriate Chapter. If a specific pattern is not given, the following procedures can be used to prevent warping.

Initially, the bolts or nuts should be assembled finger-tight only. Next, they should be tightened one full turn each, in a criss-cross or diagonal pattern. After each one has been tightened one full turn, return to the first one and tighten them all one-half turn, following the same pattern. Finally, tighten each of them one-quarter turn at a time until each fastener has been tightened to the proper torque. To loosen and remove the fasteners, the procedure would be reversed.

Component disassembly

Component disassembly should be done with care and purpose to help ensure that the parts go back together properly. Always keep track of the sequence in which parts are removed. Make note of special characteristics or marks on parts that can be installed more than one way, such as a grooved thrust washer on a shaft. It is a good idea to lay the disassembled parts out on a clean surface in the order that they were removed. It may also be helpful to make sketches or take instant photos of components before removal.

When removing fasteners from a component, keep track of their locations. Sometimes threading a bolt back in a part, or putting the washers and nut back on a stud, can prevent mix-ups later. If nuts and bolts cannot be returned to their original locations, they should be kept in a compartmented box or a series of small boxes. A cupcake or muffin tin is ideal for this purpose, since each cavity can hold the bolts and nuts from a particular area (i.e. oil pan bolts, valve cover bolts, engine mount bolts, etc.). A pan of this type is especially helpful when working on assemblies with very small parts, such as the carburetor, alternator, valve train or interior dash and trim pieces. The cavities can be marked with paint or tape to identify the contents.

Whenever wiring looms, harnesses or connectors are separated, it is a good idea to identify the two halves with numbered pieces of masking tape so they can be easily reconnected.

Gasket sealing surfaces

Throughout any vehicle, gaskets are used to seal the mating surfaces between two parts and keep lubricants, fluids, vacuum or pressure contained in an assembly.

Many times these gaskets are coated with a liquid or paste-type gasket sealing compound before assembly. Age, heat and pressure can sometimes cause the two parts to stick together so tightly that they are very difficult to separate. Often, the assembly can be loosened by striking it with a soft-face hammer near the mating surfaces. A regular hammer can be used if a block of wood is placed between the hammer and the part. Do not hammer on cast parts or parts that could be easily damaged. With any particularly stubborn part, always recheck to make sure that every fastener has been removed.

Avoid using a screwdriver or bar to pry apart an assembly, as they can easily mar the gasket sealing surfaces of the parts, which must remain smooth. If prying is absolutely necessary, use an old broom

handle, but keep in mind that extra clean up will be necessary if the wood splinters.

After the parts are separated, the old gasket must be carefully scraped off and the gasket surfaces cleaned. Stubborn gasket material can be soaked with rust penetrant or treated with a special chemical to soften it so it can be easily scraped off. A scraper can be fashioned from a piece of copper tubing by flattening and sharpening one end. Copper is recommended because it is usually softer than the surfaces to be scraped, which reduces the chance of gouging the part. Some gaskets can be removed with a wire brush, but regardless of the method used, the mating surfaces must be left clean and smooth. If for some reason the gasket surface is gouged, then a gasket sealer thick enough to fill scratches will have to be used during reassembly of the components. For most applications, a non-drying (or semi-drying) gasket sealer should be used.

Hose removal tips

Warning: If the vehicle is equipped with air conditioning, do not disconnect any of the A/C hoses without first having the system depressurized by a dealer service department or an air conditioning specialist.


Hose removal precautions closely parallel gasket removal precautions. Avoid scratching or gouging the surface that the hose mates against or the connection may leak. This is especially true for radiator hoses. Because of various chemical reactions, the rubber in hoses can bond itself to the metal spigot that the hose fits over. To remove a hose, first loosen the hose clamps that secure it to the spigot. Then, with slip-joint pliers, grab the hose at the clamp and rotate it around the spigot. Work it back and forth until it is completely free, then pull it off. Silicone or other lubricants will ease removal if they can be applied between the hose and the outside of the spigot. Apply the same lubricant to the inside of the hose and the outside of the spigot to simplify installation.

As a last resort (and if the hose is to be replaced with a new one anyway), the rubber can be slit with a knife and the hose peeled from the spigot. If this must be done, be careful that the metal connection is not damaged.


If a hose clamp is broken or damaged, do not reuse it. Wire-type clamps usually weaken with age, so it is a good idea to replace them with screw-type clamps whenever a hose is removed.

Tools


A selection of good tools is a basic requirement for anyone who plans to maintain and repair his or her own vehicle. For the owner who has few tools, the initial investment might seem high, but when compared to the spiraling costs of professional auto maintenance and repair, it is a wise one.




Micrometer set




Dial indicator set




Dial caliper




Hand-operated vacuum pump




Timing light



Compression gauge with spark plug hole adapter




Damper/steering wheel puller




General purpose puller




Hydraulic lifter removal tool




Valve spring compressor




Valve spring compressor




Ridge reamer




Piston ring groove cleaning tool




Ring removal/installation tool




Ring compressor




Cylinder hone




Brake hold-down spring tool



Brake cylinder hone



Clutch plate alignment tool



Tap and die set

To help the owner decide which tools are needed to perform the tasks detailed in this manual, the following tool lists are offered: *Maintenance and minor repair*, *Repair/overhaul* and *Special*.

The newcomer to practical mechanics should start off with the maintenance and minor repair tool kit, which is adequate for the simpler jobs performed on a vehicle. Then, as confidence and experience grow, the owner can tackle more difficult tasks, buying additional tools as they are needed. Eventually the basic kit will be expanded into the repair and overhaul tool set. Over a period of time, the experienced do-it-yourselfer will assemble a tool set complete enough for most repair and overhaul procedures and will add tools from the special category when it is felt that the expense is justified by the frequency of use.

Maintenance and minor repair tool kit

The tools in this list should be considered the minimum required for performance of routine maintenance, servicing and minor repair work. We recommend the purchase of combination wrenches (box-end and open-end combined in one wrench). While more expensive than open end wrenches, they offer the advantages of both types of wrench.

Combination wrench set (1/4-inch to 1 inch or 6 mm to 19 mm)
Adjustable wrench, 8 inch
Spark plug wrench with rubber insert
Spark plug gap adjusting tool
Feeler gauge set
Brake bleeder wrench
Standard screwdriver (5/16-inch x 6 inch)
Phillips screwdriver (No. 2 x 6 inch)
Combination pliers — 6 inch
Hacksaw and assortment of blades
Tire pressure gauge
Grease gun
Oil can
Fine emery cloth
Wire brush

Battery post and cable cleaning tool
Oil filter wrench
Funnel (medium size)
Safety goggles
Jackstands (2)
Drain pan

Note: If basic tune-ups are going to be part of routine maintenance, it will be necessary to purchase a good quality stroboscopic timing light and combination tachometer/dwell meter. Although they are included in the list of special tools, it is mentioned here because they are absolutely necessary for tuning most vehicles properly.

Repair and overhaul tool set

These tools are essential for anyone who plans to perform major repairs and are in addition to those in the maintenance and minor repair tool kit. Included is a comprehensive set of sockets which, though expensive, are invaluable because of their versatility, especially when various extensions and drives are available. We recommend the 1/2-inch drive over the 3/8-inch drive. Although the larger drive is bulky and more expensive, it has the capacity of accepting a very wide range of large sockets. Ideally, however, the mechanic should have a 3/8-inch drive set and a 1/2-inch drive set.

Socket set(s)
Reversible ratchet
Extension — 10 inch
Universal joint
Torque wrench (same size drive as sockets)
Ball peen hammer — 8 ounce
Soft-face hammer (plastic/rubber)
Standard screwdriver (1/4-inch x 6 inch)
Standard screwdriver (stubby — 5/16-inch)
Phillips screwdriver (No. 3 x 8 inch)
Phillips screwdriver (stubby — No. 2)

Pliers — vise grip
Pliers — lineman's
Pliers — needle nose
Pliers — snap-ring (internal and external)
Cold chisel — 1/2-inch
Scribe
Scraper (made from flattened copper tubing)
Centerpunch
Pin punches (1/16, 1/8, 3/16-inch)
Steel rule/straightedge — 12 inch
Allen wrench set (1/8 to 3/8-inch or 4 mm to 10 mm)
A selection of files
Wire brush (large)
Jackstands (second set)
Jack (scissor or hydraulic type)

Note: Another tool which is often useful is an electric drill motor with a chuck capacity of 3/8-inch and a set of good quality drill bits.

Special tools

The tools in this list include those which are not used regularly, are expensive to buy, or which need to be used in accordance with their manufacturer's instructions. Unless these tools will be used frequently, it is not very economical to purchase many of them. A consideration would be to split the cost and use between yourself and a friend or friends. In addition, most of these tools can be obtained from a tool rental shop on a temporary basis.

This list primarily contains only those tools and instruments widely available to the public, and not those special tools produced by the vehicle manufacturer for distribution to dealer service departments. Occasionally, references to the manufacturer's special tools are included in the text of this manual. Generally, an alternative method of doing the job without the special tool is offered. However, sometimes there is no alternative to their use. Where this is the case, and the tool cannot be purchased or borrowed, the work should be turned over to the dealer service department or an automotive repair shop.

Valve spring compressor
Piston ring groove cleaning tool
Piston ring compressor
Piston ring installation tool
Cylinder compression gauge
Cylinder ridge reamer
Cylinder surfacing hone
Cylinder bore gauge
Micrometers and/or dial calipers
Hydraulic lifter removal tool
Balljoint separator
Universal-type puller
Impact screwdriver
Dial indicator set
Stroboscopic timing light (inductive pick-up)
Hand operated vacuum/pressure pump
Tachometer/dwell meter
Universal electrical multimeter
Cable hoist
Brake spring removal and installation tools
Floor jack

Buying tools

For the do-it-yourselfer who is just starting to get involved in vehicle maintenance and repair, there are a number of options available when purchasing tools. If maintenance and minor repair is the extent of the work to be done, the purchase of individual tools is satisfactory. If,

on the other hand, extensive work is planned, it would be a good idea to purchase a modest tool set from one of the large retail chain stores. A set can usually be bought at a substantial savings over the individual tool prices, and they often come with a tool box. As additional tools are needed, add-on sets, individual tools and a larger tool box can be purchased to expand the tool selection. Building a tool set gradually allows the cost of the tools to be spread over a longer period of time and gives the mechanic the freedom to choose only those tools that will actually be used.

Tool stores will often be the only source of some of the special tools that are needed, but regardless of where tools are bought, try to avoid cheap ones, especially when buying screwdrivers and sockets, because they won't last very long. The expense involved in replacing cheap tools will eventually be greater than the initial cost of quality tools.

Care and maintenance of tools

Good tools are expensive, so it makes sense to treat them with respect. Keep them clean and in usable condition and store them properly when not in use. Always wipe off any dirt, grease or metal chips before putting them away. Never leave tools lying around in the work area. Upon completion of a job, always check closely under the hood for tools that may have been left there so they won't get lost during a test drive.

Some tools, such as screwdrivers, pliers, wrenches and sockets, can be hung on a panel mounted on the garage or workshop wall, while others should be kept in a tool box or tray. Measuring instruments, gauges, meters, etc. must be carefully stored where they cannot be damaged by weather or impact from other tools.

When tools are used with care and stored properly, they will last a very long time. Even with the best of care, though, tools will wear out if used frequently. When a tool is damaged or worn out, replace it. Subsequent jobs will be safer and more enjoyable if you do.

Working facilities

Not to be overlooked when discussing tools is the workshop. If anything more than routine maintenance is to be carried out, some sort of suitable work area is essential.

It is understood, and appreciated, that many home mechanics do not have a good workshop or garage available, and end up removing an engine or doing major repairs outside. It is recommended, however, that the overhaul or repair be completed under the cover of a roof.

A clean, flat workbench or table of comfortable working height is an absolute necessity. The workbench should be equipped with a vise that has a jaw opening of at least four inches.

As mentioned previously, some clean, dry storage space is also required for tools, as well as the lubricants, fluids, cleaning solvents, etc. which will soon become necessary.

Sometimes waste oil and fluids, drained from the engine or cooling system during normal maintenance or repairs, present a disposal problem. To avoid pouring them on the ground or into a sewage system, pour the used fluids into large containers, seal them with caps and take them to an authorized disposal site or recycling center. Plastic jugs, such as old antifreeze containers, are ideal for this purpose.

Always keep a supply of old newspapers and clean rags available. Old towels are excellent for mopping up spills. Many mechanics use rolls of paper towels for most work because they are readily available and disposable. To help keep the area under the vehicle clean, a large cardboard box can be cut open and flattened to protect the garage or shop floor.

Whenever working over a painted surface, such as when leaning over a fender to service something under the hood, always cover it with an old blanket or bedspread to protect the finish. Vinyl covered pads, made especially for this purpose, are available at auto parts stores.

Booster battery (jump) starting


Certain precautions must be observed when using a booster battery to jump start a vehicle.

- a) Before connecting the booster battery, make sure that the ignition switch is in the Off position.
- b) Turn off the lights, heater and other electrical loads.
- c) The eyes should be shielded. Safety goggles are a good idea.
- d) Make sure the booster battery is the same voltage as the dead one in the vehicle.
- e) The two vehicles must not touch each other.
- f) Make sure the transmission is in Neutral (manual transmission) or Park (automatic transmission).
- g) If the booster battery is not a maintenance-free type, remove the vent caps and lay a cloth over the vent holes.

Connect the red jumper cable to the *positive* (+) terminals of each battery.

Connect one end of the black jumper cable to the *negative* (–) terminal of the booster battery. The other end of this cable should be connected to a good ground on the vehicle to be started, such as a bolt or bracket on the engine block. Use caution to ensure that the cable will not come into contact with the fan, drivebelts or other moving parts of the engine.

Start the engine using the booster battery, then, with the engine running at idle speed, disconnect the jumper cables in the reverse order of connection.



Booster cable connections (note that the negative cable is *not* attached to the negative terminal of the dead battery)

Jacking and towing

Jacking

The jack supplied with the vehicle should only be used for raising the vehicle when changing a tire or placing jackstands under the frame. **Caution:** *Never work under the vehicle or start the engine while this jack is being used as the only means of support.*

The vehicle should be on level ground with the wheels blocked and the transmission in Park (automatic) or Reverse (manual). If the wheel is being replaced, loosen the wheel nuts one-half turn and leave them in place until the wheel is raised off the ground. Refer to Chapter 10 for the tire changing procedure.

Place the jack under the side of the vehicle in the indicated position and raise it until the jack head groove fits into the rocker flange notch. **Caution:** *Carefully read the caution label attached to the jack body. Operate the jack with a slow, smooth motion until the wheel is raised off the ground.*

Lower the vehicle, remove the jack and tighten the nuts (if loosened or removed) in a criss-cross sequence by turning the wrench clockwise.

Towing


The vehicle can be towed with all four wheels on the ground, provided that speeds do not exceed 30 mph and the distance is not over 40 miles, otherwise transmission damage can result. **Caution:** *Front towing is not recommended with conventional sling type equipment on the turbocharged models because the towing rope or chain will come into contact with the spoiler and damage may result. With manual transmission equipped models, restrict towing speed to below 50 mph and towing distance to less than 50 miles. If the speed or distance to be towed is greater than the recommended speed and distance (both models), remove the driveshaft to prevent damage to the transmission.*

Towing equipment specifically designed for this purpose should be used and should be attached to the main structural members of the


vehicle and not the bumper or brackets.

Safety is a major consideration when towing and all applicable state and local laws must be obeyed. A safety chain system must be used for all towing.



While towing, the parking brake should be released and the transmission should be in Neutral. The steering must be unlocked (ignition switch in the Off position). Remember that power steering and power brakes will not work with the engine off.



The jack head groove fits into the rocker panel flange notch






For towing and tie-down hooks



Tie-down hook

For towing and tie-down hooks



Jackstands should be correctly positioned to properly support the vehicle, jacking should only be done at the designated hardpoints and front and rear brackets are provided for tie down and towing

Acknowledgements

We are grateful for the help and cooperation of the Nissan Motor Co., Ltd. for their assistance with technical information, certain illustrations and vehicle photos.

© Haynes North America, Inc. 1991

With permission from J.H. Haynes & Co. Ltd.

A book in the **Haynes Automotive Repair Manual Series**

Printed in the U.S.A.

All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.

ISBN 1 85010 563 4

Library of Congress Catalog Card Number 91-70710

While every attempt is made to ensure that the information in this manual is correct, no liability can be accepted by the authors or publishers for loss, damage or injury caused by any errors in, or omissions from, the information given.

Safety first!

Regardless of how enthusiastic you may be about getting on with the job at hand, take the time to ensure that your safety is not jeopardized. A moment's lack of attention can result in an accident, as can failure to observe certain simple safety precautions. The possibility of an accident will always exist, and the following points should not be considered a comprehensive list of all dangers. Rather, they are intended to make you aware of the risks and to encourage a safety-conscious approach to all work you carry out on your vehicle.

Essential DOs and DON'Ts

DON'T rely on a jack when working under the vehicle. Always use approved jackstands to support the weight of the vehicle and place them under the recommended lift or support points.

DON'T attempt to loosen extremely tight fasteners (i.e. wheel lug nuts) while the vehicle is on a jack — it may fall.

DON'T start the engine without first making sure that the transmission is in Neutral (or Park where applicable) and the parking brake is set.

DON'T remove the radiator cap from a hot cooling system — let it cool or cover it with a cloth and release the pressure gradually.

DON'T attempt to drain the engine oil until you are sure it has cooled to the point that it will not burn you.

DON'T touch any part of the engine or exhaust system until it has cooled sufficiently to avoid burns.

DON'T siphon toxic liquids such as gasoline, antifreeze and brake fluid by mouth, or allow them to remain on your skin.

DON'T inhale brake lining dust — it is potentially hazardous (see *Asbestos* below)

DON'T allow spilled oil or grease to remain on the floor — wipe it up before someone slips on it.

DON'T use loose fitting wrenches or other tools which may slip and cause injury.

DON'T push on wrenches when loosening or tightening nuts or bolts. Always try to pull the wrench toward you. If the situation calls for pushing the wrench away, push with an open hand to avoid scraped knuckles if the wrench should slip.

DON'T attempt to lift a heavy component alone — get someone to help you.

DON'T rush or take unsafe shortcuts to finish a job.

DON'T allow children or animals in or around the vehicle while you are working on it.

DO wear eye protection when using power tools such as a drill, sander, bench grinder, etc. and when working under a vehicle.

DO keep loose clothing and long hair well out of the way of moving parts.

DO make sure that any hoist used has a safe working load rating adequate for the job.

DO get someone to check on you periodically when working alone on a vehicle.

DO carry out work in a logical sequence and make sure that everything is correctly assembled and tightened.

DO keep chemicals and fluids tightly capped and out of the reach of children and pets.

DO remember that your vehicle's safety affects that of yourself and others. If in doubt on any point, get professional advice.

Asbestos

Certain friction, insulating, sealing, and other products — such as brake linings, brake bands, clutch linings, torque converters, gaskets, etc. — contain asbestos. *Extreme care must be taken to avoid inhalation of dust from such products since it is hazardous to health.* If in doubt, assume that they *do* contain asbestos.

Fire

Remember at all times that gasoline is highly flammable. Never smoke or have any kind of open flame around when working on a vehicle. But the risk does not end there. A spark caused by an electrical short circuit, by two metal surfaces contacting each other, or even by static electricity built up in your body under certain conditions, can ignite gasoline vapors, which in a confined space are highly explosive. Do not, under any circumstances, use gasoline for cleaning parts. Use an approved safety solvent.

Always disconnect the battery ground (–) cable *at the battery* before working on any part of the fuel system or electrical system. Never risk spilling fuel on a hot engine or exhaust component.

It is strongly recommended that a fire extinguisher suitable for use on fuel and electrical fires be kept handy in the garage or workshop at all times. Never try to extinguish a fuel or electrical fire with water.

Fumes

Certain fumes are highly toxic and can quickly cause unconsciousness and even death if inhaled to any extent. Gasoline vapor falls into this category, as do the vapors from some cleaning solvents. Any draining or pouring of such volatile fluids should be done in a well ventilated area.

When using cleaning fluids and solvents, read the instructions on the container carefully. Never use materials from unmarked containers.

Never run the engine in an enclosed space, such as a garage. Exhaust fumes contain carbon monoxide, which is extremely poisonous. If you need to run the engine, always do so in the open air, or at least have the rear of the vehicle outside the work area.

If you are fortunate enough to have the use of an inspection pit, never drain or pour gasoline and never run the engine while the vehicle is over the pit. The fumes, being heavier than air, will concentrate in the pit with possibly lethal results.

The battery

Never create a spark or allow a bare light bulb near the battery. The battery normally gives off a certain amount of hydrogen gas, which is highly explosive.

Always disconnect the battery ground (–) cable *at the battery* before working on the fuel or electrical systems.

If possible, loosen the filler caps or cover when charging the battery from an external source. Do not charge at an excessive rate or the battery may burst.

Take care when adding water and when carrying a battery. The electrolyte, even when diluted, is very corrosive and should not be allowed to contact clothing or skin.

Always wear eye protection when cleaning the battery to prevent the caustic deposits from entering your eyes.

Household current

When using an electric power tool, inspection light, etc., which operates on household current, always make sure that the tool is correctly connected to its plug and that, where necessary, it is properly grounded. Do not use such items in damp conditions and, again, do not create a spark or apply excessive heat in the vicinity of fuel or fuel vapor.

Secondary ignition system voltage

A severe electric shock can result from touching certain parts of the ignition system (such as the spark plug wires) when the engine is running or being cranked, particularly if components are damp or the insulation is defective. In the case of an electronic ignition system, the secondary system voltage is much higher and could prove fatal.

Automotive chemicals and lubricants

A number of automotive chemicals and lubricants are available for use during vehicle maintenance and repair. They include a wide variety of products ranging from cleaning solvents and degreasers to lubricants and protective sprays for rubber, plastic and vinyl.

Cleaners

Carburetor cleaner and choke cleaner is a strong solvent for gum, varnish and carbon. Most carburetor cleaners leave a dry-type lubricant film which will not harden or gum up. Because of this film it is not recommended for use on electrical components.

Brake system cleaner is used to remove grease and brake fluid from the brake system where clean surfaces are absolutely necessary. It leaves no residue and often eliminates brake squeal caused by contaminants.

Electrical cleaner removes oxidation, corrosion and carbon deposits from electrical contacts, restoring full current flow. It can also be used to clean spark plugs, carburetor jets, voltage regulators and other parts where an oil-free surface is desired.

Demoisturants remove water and moisture from electrical components such as alternators, voltage regulators, electrical connectors and fuse blocks. It is non-conductive, non-corrosive and non-flammable.

Degreasers are heavy-duty solvents used to remove grease from the outside of the engine and from chassis components. They can be sprayed or brushed on, and, depending on the type, are rinsed off either with water or solvent.

Lubricants

Motor oil is the lubricant formulated for use in engines. It normally contains a wide variety of additives to prevent corrosion and reduce foaming and wear. Motor oil comes in various weights (viscosity ratings) from 5 to 80. The recommended weight of the oil depends on the season, temperature and the demands on the engine. Light oil is used in cold climates and under light load conditions. Heavy oil is used in hot climates and where high loads are encountered. Multi-viscosity oils are designed to have characteristics of both light and heavy oils and are available in a number of weights from 5W-20 to 20W-50.

Gear oil is designed to be used in differentials, manual transaxles and other areas where high-temperature lubrication is required.

Chassis and wheel bearing grease is a heavy grease used where increased loads and friction are encountered, such as for wheel bearings, balljoints, tie rod ends and universal joints.

High temperature wheel bearing grease is designed to withstand the extreme temperatures encountered by wheel bearings in disc brake equipped vehicles. It usually contains molybdenum disulfide (moly), which is a dry-type lubricant.

White grease is a heavy grease for metal to metal applications where water is a problem. White grease stays soft under both low and high temperatures (usually from -100°F to +190°F), and will not wash off or dilute in the presence of water.

Assembly lube is a special extreme pressure lubricant, usually containing moly, used to lubricate high-load parts such as main and rod bearings and cam lobes for initial start-up of a new engine. The assembly lube lubricates the parts without being squeezed out or washed away until the engine oiling system begins to function.

Silicone lubricants are used to protect rubber, plastic, vinyl and nylon parts.

Graphite lubricants are used where oils cannot be used due to contamination problems, such as in locks. The dry graphite will lubricate metal parts while remaining uncontaminated by dirt, water, oil or acids. It is electrically conductive and will not foul electrical contacts in locks such as the ignition switch.

Moly penetrants loosen and lubricate frozen, rusted and corroded fasteners and prevent future rusting or freezing.

Heat-sink grease is a special electrically non-conductive grease that

is used for mounting HEI ignition modules where it is essential that heat be transferred away from the module.

Sealants

RTV sealant is one of the most widely used gasket compounds. Made from silicone, RTV is air curing, it seals, bonds, waterproofs, fills surface irregularities, remains flexible, doesn't shrink, is relatively easy to remove, and is used as a supplementary sealer with almost all low and medium temperature gaskets.

Anaerobic sealant is much like RTV in that it can be used either to seal gaskets or to form gaskets by itself. It remains flexible, is solvent resistant and fills surface imperfections. The difference between an anaerobic sealant and an RTV-type sealant is in the curing. RTV cures when exposed to air, while an anaerobic sealant cures only in the absence of air. This means that an anaerobic sealant cures only after the assembly of parts, sealing them together.

Thread and pipe sealant is used for sealing hydraulic and pneumatic fittings and vacuum lines. It is usually made from a teflon compound, and comes in a spray, a paint-on liquid and as a wrap-around tape.

Chemicals

Anti-seize compound prevents seizing, galling, cold welding, rust and corrosion in fasteners. High temperature anti-seize, usually made with copper and graphite lubricants, is used for exhaust system and manifold bolts.

Anaerobic locking compounds are used to keep fasteners from vibrating or working loose, and cure only after installation, in the absence of air. Medium strength locking compound is used for small nuts, bolts and screws that you expect to be removing later. High strength locking compound is for large nuts, bolts and studs which you don't intend to be removing on a regular basis.

Oil additives range from viscosity index improvers to chemical treatments that claim to reduce internal engine friction. It should be noted that most oil manufacturers caution against using additives with their oils.

Gas additives perform several functions, depending on their chemical makeup. They usually contain solvents that help dissolve gum and varnish that build up on carburetor and intake parts. They also serve to break down carbon deposits that form on the inside surfaces of the combustion chambers. Some additives contain upper cylinder lubricants for valves and piston rings, and others chemicals to remove condensation from the gas tank.

Other

Brake fluid is specially formulated hydraulic fluid that can withstand the heat and pressure encountered in brake systems. Care must be taken that this fluid does not come in contact with painted surfaces or plastics. An opened container should always be resealed to prevent contamination by water or dirt.

Weatherstrip adhesive is used to bond weatherstripping around doors, windows and trunk lids. It is sometimes used to attach trim pieces.

Undercoating is a petroleum-based tar-like substance that is designed to protect metal surfaces on the underside of the vehicle from corrosion. It also acts as a sound-deadening agent by insulating the bottom of the vehicle.

Waxes and polishes are used to help protect painted and plated surfaces from the weather. Different types of paint may require the use of different types of wax and polish. Some polishes utilize a chemical or abrasive cleaner to help remove the top layer of oxidized (dull) paint on older vehicles. In recent years many non-wax polishes that contain a wide variety of chemicals such as polymers and silicones have been introduced. These non-wax polishes are usually easier to apply and last longer than conventional waxes and polishes.

Conversion factors

Length (distance)

Inches (in)	X	25.4	=	Millimetres (mm)	X	0.0394	=	Inches (in)
Feet (ft)	X	0.305	=	Metres (m)	X	3.281	=	Feet (ft)
Miles	X	1.609	=	Kilometres (km)	X	0.621	=	Miles

Volume (capacity)

Cubic inches (cu in; in ³)	X	16.387	=	Cubic centimetres (cc; cm ³)	X	0.061	=	Cubic inches (cu in; in ³)
Imperial pints (Imp pt)	X	0.568	=	Litres (l)	X	1.76	=	Imperial pints (Imp pt)
Imperial quarts (Imp qt)	X	1.137	=	Litres (l)	X	0.88	=	Imperial quarts (Imp qt)
Imperial quarts (Imp qt)	X	1.201	=	US quarts (US qt)	X	0.833	=	Imperial quarts (Imp qt)
US quarts (US qt)	X	0.946	=	Litres (l)	X	1.057	=	US quarts (US qt)
Imperial gallons (Imp gal)	X	4.546	=	Litres (l)	X	0.22	=	Imperial gallons (Imp gal)
Imperial gallons (Imp gal)	X	1.201	=	US gallons (US gal)	X	0.833	=	Imperial gallons (Imp gal)
US gallons (US gal)	X	3.785	=	Litres (l)	X	0.264	=	US gallons (US gal)

Mass (weight)

Ounces (oz)	X	28.35	=	Grams (g)	X	0.035	=	Ounces (oz)
Pounds (lb)	X	0.454	=	Kilograms (kg)	X	2.205	=	Pounds (lb)

Force

Ounces-force (ozf; oz)	X	0.278	=	Newtons (N)	X	3.6	=	Ounces-force (ozf; oz)
Pounds-force (lbf; lb)	X	4.448	=	Newtons (N)	X	0.225	=	Pounds-force (lbf; lb)
Newtons (N)	X	0.1	=	Kilograms-force (kgf; kg)	X	9.81	=	Newtons (N)

Pressure

Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X	0.070	=	Kilograms-force per square centimetre (kgf/cm ² ; kg/cm ²)	X	14.223	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X	0.068	=	Atmospheres (atm)	X	14.696	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X	0.069	=	Bars	X	14.5	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X	6.895	=	Kilopascals (kPa)	X	0.145	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Kilopascals (kPa)	X	0.01	=	Kilograms-force per square centimetre (kgf/cm ² ; kg/cm ²)	X	98.1	=	Kilopascals (kPa)
Millibar (mbar)	X	100	=	Pascals (Pa)	X	0.01	=	Millibar (mbar)
Millibar (mbar)	X	0.0145	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X	68.947	=	Millibar (mbar)
Millibar (mbar)	X	0.75	=	Millimetres of mercury (mmHg)	X	1.333	=	Millibar (mbar)
Millibar (mbar)	X	0.401	=	Inches of water (inH ₂ O)	X	2.491	=	Millibar (mbar)
Millimetres of mercury (mmHg)	X	0.535	=	Inches of water (inH ₂ O)	X	1.868	=	Millimetres of mercury (mmHg)
Inches of water (inH ₂ O)	X	0.036	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X	27.68	=	Inches of water (inH ₂ O)

Torque (moment of force)

Pounds-force inches (lbf in; lb in)	X	1.152	=	Kilograms-force centimetre (kgf cm; kg cm)	X	0.868	=	Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	X	0.113	=	Newton metres (Nm)	X	8.85	=	Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	X	0.083	=	Pounds-force feet (lbf ft; lb ft)	X	12	=	Pounds-force inches (lbf in; lb in)
Pounds-force feet (lbf ft; lb ft)	X	0.138	=	Kilograms-force metres (kgf m; kg m)	X	7.233	=	Pounds-force feet (lbf ft; lb ft)
Pounds-force feet (lbf ft; lb ft)	X	1.356	=	Newton metres (Nm)	X	0.738	=	Pounds-force feet (lbf ft; lb ft)
Newton metres (Nm)	X	0.102	=	Kilograms-force metres (kgf m; kg m)	X	9.804	=	Newton metres (Nm)

Power

Horsepower (hp)	X	745.7	=	Watts (W)	X	0.0013	=	Horsepower (hp)
-----------------	---	-------	---	-----------	---	--------	---	-----------------

Velocity (speed)

Miles per hour (miles/hr; mph)	X	1.609	=	Kilometres per hour (km/hr; kph)	X	0.621	=	Miles per hour (miles/hr; mph)
--------------------------------	---	-------	---	----------------------------------	---	-------	---	--------------------------------

Fuel consumption*

Miles per gallon, Imperial (mpg)	X	0.354	=	Kilometres per litre (km/l)	X	2.825	=	Miles per gallon, Imperial (mpg)
Miles per gallon, US (mpg)	X	0.425	=	Kilometres per litre (km/l)	X	2.352	=	Miles per gallon, US (mpg)

Temperature

Degrees Fahrenheit = (°C x 1.8) + 32

Degrees Celsius (Degrees Centigrade; °C) = (°F - 32) x 0.56

*It is common practice to convert from miles per gallon (mpg) to litres/100 kilometres (l/100km), where mpg (Imperial) x l/100 km = 282 and mpg (US) x l/100 km = 235

Troubleshooting

Contents

Symptom	Section	Symptom	Section
Engine		Manual transmission	
Engine backfires	13	Difficulty in engaging gears	41
Engine diesels (continues to run) after switching off	19	Noisy in all gears	38
Engine hard to start when cold	4	Noisy in Neutral with engine running	37
Engine hard to start when hot	5	Noisy in one particular gear	39
Engine lacks power	15	Oil leakage	42
Engine lopes while idling or idles erratically	9	Slips out of gear	40
Engine misses at idle speed	10		
Engine misses throughout driving speed range	11	Automatic transmission	
Engine rotates but will not start	2	Engine will start in gears other than Park or Neutral	47
Engine runs with oil pressure light on	18	Fluid leakage	43
Engine stalls	14	General shift mechanism problems	45
Engine starts but stops immediately	7	Transmission slips, shifts rough, is noisy or has no drive in forward or reverse gears	48
Engine stumbles on acceleration	12	Transmission will not downshift with accelerator pedal pressed to the floor	46
Engine surges while holding accelerator steady	13	Transmission fluid brown or has burned smell	44
Engine will not rotate when attempting to start	1		
Oil puddle under engine	8	Driveshaft	
Pinging or knocking engine sounds during acceleration or uphill	17	Knock or clunk when transmission is under initial load (just after transmission is put into gear)	50
Starter motor noisy or excessively rough in engagement	6	Leakage of fluid at front of driveshaft	49
Starter motor operates without rotating engine	3	Metallic grating sound consistent with road speed	51
		Vibration	52
Engine electrical system		Rear axle	
Alternator light fails to go out	21	Noise — same when in drive as when vehicle is coasting	53
Battery will not hold a charge	20	Oil leakage	55
Ignition light fails to come on when key is turned on	22	Vibration	54
Fuel system		Brakes	
Excessive fuel consumption	23	Brake pedal feels spongy when depressed	59
Fuel leakage and/or fuel odor	24	Brake pedal pulsates during brake application	62
		Excessive brake pedal travel	58
Cooling system		Excessive effort required to stop vehicle	60
Coolant loss	29	Noise (high-pitched squeal without the brakes applied)	57
External coolant leakage	27	Pedal travels to the floor with little resistance	61
Internal coolant leakage	28	Parking brake does not hold	63
Overcooling	26	Vehicle pulls to one side during braking	56
Overheating	25		
Poor coolant circulation	30	Suspension and steering systems	
Clutch		Excessive pitching and/or rolling around corners or during braking	66
Clutch slips (engine speed increases with no increase in vehicle speed)	32	Excessive play in steering	68
Clutch pedal stays on floor when disengaged	36	Excessive tire wear (not specific to one area)	70
Fails to release (pedal pressed to the floor — shift lever does not move freely in and out of Reverse)	31	Excessive tire wear on inside edge	72
Grabbing (chattering) as clutch is engaged	33	Excessive tire wear on outside edge	71
Squeal or rumble with clutch fully disengaged (pedal depressed)	35	Excessively stiff steering	67
Squeal or rumble with clutch fully engaged (pedal released)	34	Lack of power assistance	69
		Shimmy, shake or vibration	65
		Tire tread worn in one place	73
		Vehicle pulls to one side	64

This section provides an easy reference guide to the more common problems which may occur during the operation of your vehicle. These problems and possible causes are grouped under various components or systems; i.e. Engine, Cooling system, etc., and also refer to the Chapter and/or Section which deals with the problem.

Remember that successful troubleshooting is not a mysterious *black art* practiced only by professional mechanics. It's simply the result of a bit of knowledge combined with an intelligent, systematic approach to the problem. Always work by a process of elimination, starting with the simplest solution and working through to the most complex — and never overlook the obvious. Anyone can forget to fill the gas tank or leave the lights on overnight, so don't assume that you are above such oversights.

Finally, always get clear in your mind why a problem has occurred and take steps to ensure that it doesn't happen again. If the electrical system fails because of a poor connection, check all other connections in the system to make sure that they don't fail as well. If a particular fuse continues to blow, find out why — don't just go on replacing fuses. Remember, failure of a small component can often be indicative of potential failure or incorrect functioning of a more important component or system.

Engine

1 Engine will not rotate when attempting to start

- 1 Battery terminal connections loose or corroded. Check the cable terminals at the battery. Tighten the cable or remove corrosion as necessary.
- 2 Battery discharged or faulty. If the cable connections are clean and tight on the battery posts, turn the key to the On position and switch on the headlights and/or windshield wipers. If they fail to function, the battery is discharged.
- 3 Automatic transmission not completely engaged in Park or clutch not completely depressed.
- 4 Broken, loose or disconnected wiring in the starting circuit. Inspect all wiring and connectors at the battery, starter solenoid and ignition switch.
- 5 Starter motor pinion jammed in flywheel ring gear. If manual transmission, place transmission in gear and rock the vehicle to manually turn the engine. Remove starter and inspect pinion and flywheel at earliest convenience.
- 6 Starter solenoid faulty (Chapter 5).
- 7 Starter motor faulty (Chapter 5).
- 8 Ignition switch faulty (Chapter 12).

2 Engine rotates but will not start

- 1 Fuel tank empty.
- 2 Battery discharged (engine rotates slowly). Check the operation of electrical components as described in previous Section.
- 3 Battery terminal connections loose or corroded. See previous Section.
- 4 Fuel injector or fuel pump faulty (Chapter 4).
- 5 Excessive moisture on, or damage to, ignition components (Chapter 5).
- 6 Worn, faulty or incorrectly gapped spark plugs (Chapter 1).
- 7 Broken, loose or disconnected wiring in the starting circuit (see previous Section).
- 8 Distributor loose, causing ignition timing to change. Turn the distributor as necessary to start engine, then set ignition timing as soon as possible (Chapter 1).
- 9 Broken, loose or disconnected wires at the ignition coil or faulty coil (Chapter 5).

3 Starter motor operates without rotating engine

- 1 Starter pinion sticking. Remove the starter (Chapter 5) and inspect.
- 2 Starter pinion or flywheel teeth worn or broken. Remove the cover at the rear of the engine and inspect.

4 Engine hard to start when cold

- 1 Battery discharged or low. Check as described in Section 1.
- 2 Fuel supply not reaching the injection system (see Section 2).
- 3 Fuel injection system in need of overhaul (Chapter 4).
- 4 Distributor rotor carbon tracked and/or mechanical advance mechanism rusted (Chapter 5).

5 Engine hard to start when hot

- 1 Air filter clogged (Chapter 1).
- 2 Fuel not reaching the fuel injection system (see Section 2).

6 Starter motor noisy or excessively rough in engagement

- 1 Pinion or flywheel gear teeth worn or broken. Remove the cover at the rear of the engine (if so equipped) and inspect.
- 2 Starter motor mounting bolts loose or missing.

7 Engine starts but stops immediately

- 1 Loose or faulty electrical connections at distributor, coil or alternator.
- 2 Insufficient fuel reaching the fuel injector(s). See fuel pressure relief caution in Chapter 4, open line and place a container under the disconnected fuel line. Observe the flow of fuel from the line. If little or none at all, check for blockage in the lines and/or replace the fuel pump (Chapter 4).
- 3 Vacuum leak at the gasket surfaces of the intake manifold and/or fuel injection unit. Make sure that all mounting bolts/nuts are tightened securely and that all vacuum hoses connected to the fuel injection unit and manifold are positioned properly and in good condition.

8 Oil puddle under engine

- 1 Oil pan gasket and/or oil plug seal leaking. Check and replace if necessary.
- 2 Oil pressure sending unit leaking. Replace unit or seal threads with teflon tape (Chapter 5).
- 3 Rocker cover gaskets leaking at front or rear of engine.
- 4 Engine oil seals leaking at front or rear of engine.

9 Engine lopes while idling or idles erratically

- 1 Vacuum leakage. Check mounting bolts/nuts at the fuel injection unit and intake manifold for tightness. Make sure that all vacuum hoses are connected and in good condition. Use a stethoscope or a length of fuel hose held against your ear to listen for vacuum leaks while the engine is running. A hissing sound will be heard. A soapy water solution will also detect leaks. Check the fuel injector and intake manifold gasket surfaces.
- 2 Leaking EGR valve or plugged PCV valve (see Chapters 1 and 6).
- 3 Air filter clogged (Chapter 1).
- 4 Fuel pump not delivering sufficient fuel to the fuel injector (see Section 7).
- 5 Fuel injection system out of adjustment (Chapter 4).
- 6 Leaking head gasket. If this is suspected, take the vehicle to a repair shop or dealer where the engine can be pressure checked.
- 7 Timing belt worn (Chapter 2).
- 8 Camshaft lobes worn (Chapter 2).

10 Engine misses at idle speed

- 1 Spark plugs worn or not gapped properly (Chapter 1).
- 2 Faulty spark plug wires (Chapter 1).

11 Engine misses throughout driving speed range

- 1 Fuel filter clogged and/or impurities in the fuel system (Chapter 1). Also check fuel output at the fuel injector (see Section 7).
- 2 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 3 Incorrect ignition timing (Chapter 1).
- 4 Check for cracked distributor cap, disconnected distributor wires and damaged distributor components (Chapter 1).
- 5 Leaking spark plug wires (Chapter 1).
- 6 Faulty emissions system components (Chapter 6).
- 7 Low or uneven cylinder compression pressures. Remove spark plugs and test compression with gauge (Chapter 1).
- 8 Weak or faulty ignition system (Chapter 5).
- 9 Vacuum leaks at fuel injection unit, intake manifold or vacuum hoses (see Section 8).
- 10 Loose injector harness.

12 Engine stumbles on acceleration

- 1 Spark plugs fouled (Chapter 1). Clean or replace.
- 2 Fuel injection system needs adjustment or repair (Chapter 4).
- 3 Fuel filter clogged. Replace filter.
- 4 Incorrect ignition timing (Chapter 1).
- 5 Intake manifold air leak (Chapters 4 and 6).

13 Engine surges while holding accelerator steady

- 1 Intake air leak (Chapter 4).
- 2 Fuel pump faulty (Chapter 4).
- 3 Loose fuel injector harness connections.
- 4 Defective control unit.

14 Engine stalls

- 1 Idle speed incorrect (Chapter 1).
- 2 Fuel filter clogged and/or water and impurities in the fuel system (Chapter 1).
- 3 Distributor components damp or damaged (Chapter 5).
- 4 Faulty emissions system components (Chapter 6).
- 5 Faulty or incorrectly gapped spark plugs (Chapter 1). Also check spark plug wires (Chapter 1).
- 6 Vacuum leak at the carburetor/fuel injection unit, intake manifold or vacuum hoses. Check as described in Section 8.
- 7 Valve clearances incorrectly set (Chapter 2).

15 Engine lacks power

- 1 Incorrect ignition timing (Chapter 1).
- 2 Excessive play in distributor shaft. At the same time, check for worn rotor, faulty distributor cap, wires, etc. (Chapters 1 and 5).
- 3 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 4 Fuel injection unit not adjusted properly or excessively worn (Chapter 4).
- 5 Faulty coil (Chapter 5).
- 6 Brakes binding (Chapter 1).
- 7 Automatic transmission fluid level incorrect (Chapter 1).
- 8 Clutch slipping (Chapter 8).
- 9 Fuel filter clogged and/or impurities in the fuel system (Chapter 1).
- 10 Emissions control system not functioning properly (Chapter 6).
- 11 Use of substandard fuel. Fill tank with proper octane fuel.
- 12 Low or uneven cylinder compression pressures. Test with compression tester, which will detect leaking valves and/or blown head gasket (Chapter 1).

16 Engine backfires

- 1 Emissions system not functioning properly (Chapter 6).
- 2 Ignition timing incorrect (Chapter 1).

- 3 Faulty secondary ignition system. Cracked spark plug insulator, faulty plug wires, distributor cap and/or rotor (Chapters 1 and 5).
- 4 Fuel injection unit in need of adjustment or worn excessively (Chapter 4).
- 5 Vacuum leak at fuel injection unit, intake manifold or vacuum hoses. Check as described in Section 8.
- 6 Valve clearances incorrect due to valves sticking or worn valve components (Chapter 2).

17 Pinging or knocking engine sounds during acceleration or uphill

- 1 Incorrect grade of fuel. Fill tank with fuel of the proper octane rating.
- 2 Ignition timing incorrect (Chapter 1).
- 3 Fuel injection unit in need of adjustment (Chapter 4).
- 4 Improper spark plugs. Check plug type against Emissions Control Information label located in engine compartment. Also check plugs and wires for damage (Chapter 1).
- 5 Worn or damaged distributor components (Chapter 5).
- 6 Faulty emissions system (Chapter 6).
- 7 Vacuum leak. Check as described in Section 8.

18 Engine runs with oil pressure light on

- 1 Low oil level. Check oil level and add oil if necessary (Chapter 1).
- 2 Idle rpm below specification (Chapter 1).
- 3 Short in wiring circuit. Repair or replace damaged wire.
- 4 Faulty oil pressure sender. Replace sender.
- 5 Worn engine bearings and/or oil pump.

19 Engine diesels (continues to run) after switching off

- 1 Idle speed too high (Chapter 1).
- 2 Ignition timing incorrectly adjusted (Chapter 1).
- 3 Thermo-controlled air cleaner heat valve not operating properly (Chapter 6).
- 4 Excessive engine operating temperature. Probable causes of this are malfunctioning thermostat, clogged radiator, faulty water pump (Chapter 3).
- 5 EGR system malfunction.

Engine electrical system

20 Battery will not hold a charge

- 1 Alternator drivebelt defective or not adjusted properly (Chapter 1).
- 2 Electrolyte level low or battery discharged (Chapter 1).
- 3 Battery terminals loose or corroded (Chapter 1).
- 4 Alternator not charging properly (Chapter 5).
- 5 Loose, broken or faulty wiring in the charging circuit (Chapter 5).
- 6 Short in vehicle wiring causing a continual drain on battery.
- 7 Battery defective internally.

21 Alternator light fails to go out

- 1 Fault in alternator or charging circuit (Chapter 5).
- 2 Alternator drivebelt defective or not properly adjusted (Chapter 1).
- 3 Alternator voltage regulator inoperative (Chapter 5).

22 Ignition light fails to come on when key is turned on

- 1 Warning light bulb defective (Chapter 12).
- 2 Alternator faulty (Chapter 5).
- 3 Fault in the printed circuit, dash wiring or bulb holder (Chapter 12).

Fuel system**23 Excessive fuel consumption**

- 1 Dirty or clogged air filter element (Chapter 1).
- 2 Incorrectly set ignition timing (Chapter 1).
- 3 Emissions system not functioning properly (see Chapter 6).
- 4 Fuel injection system idle speed and/or mixture not adjusted properly (Chapter 1).
- 5 Fuel injection internal parts excessively worn or damaged (Chapter 4).
- 6 Low tire pressure or incorrect tire size (Chapter 1).

24 Fuel leakage and/or fuel odor

- 1 Leak in a fuel feed or vent line (Chapter 4).
- 2 Tank overfilled. Fill only to automatic shut off.
- 3 Emissions system filter clogged (Chapter 1).
- 4 Vapor leaks from system lines (Chapter 4).
- 5 Fuel injection internal parts excessively worn or out of adjustment (Chapter 4).

Cooling system**25 Overheating**

- 1 Insufficient coolant in system (Chapter 1).
- 2 Water pump drivebelt defective or not adjusted properly (Chapter 1).
- 3 Radiator core blocked or radiator grille dirty and restricted (Chapter 3).
- 4 Thermostat faulty (Chapter 3).
- 5 Fan blades broken or cracked (Chapter 3).
- 6 Radiator cap not maintaining proper pressure. Have cap pressure tested by gas station or repair shop.
- 7 Ignition timing incorrect (Chapter 1).
- 8 Defective water pump (Chapter 3).

26 Overcooling

- 1 Thermostat faulty (Chapter 3).
- 2 Inaccurate temperature gauge (Chapter 12)

27 External coolant leakage

- 1 Deteriorated or damaged hoses or loose clamps. Replace hoses and/or tighten clamps at hose connections (Chapter 1).
- 2 Water pump seals defective. If this is the case, water will drip from the weep hole in the water pump body (Chapter 1).
- 3 Leakage from radiator core or header tank. This will require the radiator to be professionally repaired (see Chapter 3 for removal procedures).
- 4 Engine drain plugs or water jacket core plugs leaking (see Chapter 2).

28 Internal coolant leakage

Note: Internal coolant leaks can usually be detected by examining the oil. Check the dipstick and inside of the rocker arm cover for water deposits and an oil consistency like that of a milkshake.

- 1 Leaking cylinder head gasket. Have the cooling system pressure tested.
- 2 Cracked cylinder bore or cylinder head. Dismantle engine and inspect (Chapter 2).
- 3 Loose cylinder head bolts (Chapter 2).

29 Coolant loss

- 1 Too much coolant in system (Chapter 1).
- 2 Coolant boiling away due to overheating (see Section 16).
- 3 Internal or external leakage (see Sections 25 and 26).
- 4 Faulty radiator cap. Have the cap pressure tested.

30 Poor coolant circulation

- 1 Inoperative water pump. A quick test is to pinch the top radiator hose closed with your hand while the engine is idling, then let it loose. You should feel the surge of coolant if the pump is working properly (Chapter 1).
- 2 Restriction in cooling system. Drain, flush and refill the system (Chapter 1). If necessary, remove the radiator (Chapter 3) and have it reverse flushed.
- 3 Water pump drivebelt defective or not adjusted properly (Chapter 1).
- 4 Thermostat sticking (Chapter 3).

Clutch**31 Fails to release (pedal pressed to the floor — shift lever does not move freely in and out of Reverse)**

- 1 Improper linkage free play adjustment (Chapter 8).
- 2 Clutch fork off ball stud. Look under the vehicle, on the left side of transmission.
- 3 Clutch plate warped or damaged (Chapter 8).

32 Clutch slips (engine speed increases with no increase in vehicle speed)

- 1 Linkage out of adjustment (Chapter 8).
- 2 Clutch plate oil soaked or lining worn. Remove clutch (Chapter 8) and inspect.
- 3 Clutch plate not seated. It may take 30 or 40 normal starts for a new one to seat.
- 4 Warped flywheel (Chapter 2).

33 Grabbing (chattering) as clutch is engaged

- 1 Oil on clutch plate lining. Remove (Chapter 8) and inspect. Correct any leakage source.
- 2 Worn or loose engine or transmission mounts. These units move slightly when clutch is released. Inspect mounts and bolts.
- 3 Worn splines on clutch plate hub. Remove clutch components (Chapter 8) and inspect.
- 4 Warped pressure plate or flywheel. Remove clutch components and inspect.
- 5 Hardened or warped clutch disc facing.

34 Squeal or rumble with clutch fully engaged (pedal released)

- 1 Improper adjustment — no free play (Chapter 1).
- 2 Release bearing binding on transmission bearing retainer. Remove clutch components (Chapter 8) and check bearing. Remove any burrs or nicks, clean and relubricate before reinstallation.
- 3 Weak linkage return spring. Replace the spring.
- 4 Cracked clutch disc.

35 Squeal or rumble with clutch fully disengaged (pedal depressed)

- 1 Worn, defective or broken release bearing (Chapter 8).
- 2 Worn or broken pressure plate springs or diaphragm fingers (Chapter 8).

36 Clutch pedal stays on floor when disengaged

- 1 Bind in linkage or release bearing. Inspect linkage or remove clutch components as necessary.
- 2 Linkage springs being over extended. Adjust linkage for proper free play. Make sure proper pedal stop (bumper) is installed.

Manual transmission

37 Noisy in Neutral with engine running

- 1 Input shaft bearing worn.
- 2 Damaged main drive gear bearing.
- 3 Worn countershaft bearings.
- 4 Worn or damaged countershaft end play shims.

38 Noisy in all gears

- 1 Any of the above causes, and/or:
- 2 Insufficient lubricant (see checking procedures in Chapter 1).
- 3 Worn or damaged output shaft or bearings.

39 Noisy in one particular gear

- 1 Worn, damaged or chipped gear teeth for that particular gear.
- 2 Worn or damaged synchronizer for that particular gear.

40 Slips out of gear

- 1 Transmission loose on clutch housing (Chapter 7).
- 2 Shift rods interfering with engine mounts or clutch lever (Chapter 7).
- 3 Shift rods not working freely (Chapter 7).
- 4 Damaged mainshaft pilot bearing.
- 5 Dirt between transmission case and engine or misalignment of transmission (Chapter 7).
- 6 Worn or improperly adjusted linkage (Chapter 7).
- 7 Worn synchro units.

41 Difficulty in engaging gears

- 1 Clutch not releasing completely (see clutch adjustment in Chapter 8).
- 2 Loose, damaged or out-of-adjustment shift linkage. Make a thorough inspection, replacing parts as necessary (Chapter 7).

42 Oil leakage

- 1 Excessive amount of lubricant in transmission (see Chapter 1 for correct checking procedures). Drain lubricant as required.
- 2 Side cover loose or gasket damaged.
- 3 Rear oil seal or speedometer oil seal in need of replacement (Chapter 7).

Automatic transmission

Note: Due to the complexity of the automatic transmission, it is difficult for the home mechanic to properly diagnose and service this component. For problems other than the following, the vehicle should be taken to a dealer or reputable mechanic.

43 Fluid leakage

- 1 Automatic transmission fluid is a deep red color. Fluid leaks should not be confused with engine oil, which can easily be blown by air flow

to the transmission.

- 2 To pinpoint a leak, first remove all built-up dirt and grime from around the transmission. Degreasing agents and/or steam cleaning will achieve this. With the underside clean, drive the vehicle at low speeds so air flow will not blow the leak far from its source. Raise the vehicle and determine where the leak is coming from. Common areas of leakage are:

- a) Pan: Tighten mounting bolts and/or replace pan gasket as necessary (see Chapters 1 and 7).
- b) Filler pipe: Replace the rubber seal where pipe enters transmission case.
- c) Transmission oil lines: Tighten connectors where lines enter transmission case and/or replace lines.
- d) Speedometer connector: Replace the O-ring where speedometer cable enters transmission case (Chapter 7).

44 Transmission fluid brown or has a burned smell

- 1 Transmission fluid burned. Replace fluid. Do not overfill.

45 General shift mechanism problems

- 1 Chapter 7B deals with checking and adjusting the shift linkage on automatic transmissions. Common problems which may be attributed to poorly adjusted linkage are:
 - a) Engine starting in gears other than Park or Neutral.
 - b) Indicator on shifter pointing to a gear other than the one actually being used.
 - c) Vehicle moves when in Park.
- 2 Refer to Chapter 7B to adjust the linkage.

46 Transmission will not downshift with accelerator pedal pressed to the floor

- 1 Chapter 7B deals with adjusting the throttle valve (TV) cable to enable the transmission to downshift properly.

47 Engine will start in gears other than Park or Neutral

- 1 Chapter 7B deals with adjusting the neutral start switches used on automatic transmissions.

48 Transmission slips, shifts rough, is noisy or has no drive in forward or reverse gears

- 1 There are many probable causes for the above problems, but the home mechanic should be concerned with only one possibility — fluid level.
- 2 Before taking the vehicle to a repair shop, check the level and condition of the fluid as described in Chapter 1. Correct fluid level as necessary or change the fluid and filter if needed. If the problem persists, have a professional diagnose the probable cause.

Driveshaft

49 Leakage of fluid at front of driveshaft

- 1 Defective transmission rear oil seal. See Chapter 7B for replacement procedures. While this is done, check the splined yoke for burrs or a rough condition which may be damaging the seal. If found, these can be removed with emery cloth or a fine abrasive stone.

50 Knock or clunk when transmission is put under initial load (just after transmission is put into gear)

- 1 Loose or disconnected rear suspension components. Check all mounting bolts and bushings (Chapter 10).
- 2 Loose driveshaft bolts. Inspect all bolts and nuts and tighten to specification (Chapter 8).
- 3 Worn or damaged universal joint bearings. Test for wear (Chapter 8).
- 4 Worn mainshaft splines.

51 Metallic grating sound consistent with road speed

- 1 Pronounced wear in the universal joint bearings. Test for wear (Chapter 8).

52 Vibration

Note: Before it can be assumed that the driveshaft is at fault, make sure the tires are perfectly balanced and perform the following test.

- 1 Install a tachometer inside the car to monitor engine speed as the car is driven. Drive the car and note the engine speed at which the vibration is most pronounced. Now shift the transmission to a different gear and bring the engine speed to the same point.
- 2 If the vibration occurs at the same engine speed (rpm) regardless of which gear the transmission is in, the driveshaft is *Not* at fault since the driveshaft speed varies.
- 3 If the vibration decreases or is eliminated when the transmission is in a different gear at the same engine speed, refer to the following probable causes:
- 4 Bent or dented driveshaft. Inspect and replace as necessary (Chapter 8).
- 5 Undercoating or built-up dirt, etc. on the driveshaft. Clean the shaft thoroughly and test.
- 6 Worn universal joint bearings. Remove and inspect (Chapter 8).
- 7 Driveshaft and/or companion flange out of balance. Check for missing weights on the shaft. Remove the driveshaft and reinstall 180° from original position. Retest. Have driveshaft professionally balanced if problem persists.
- 8 Driveshaft improperly installed (Chapter 8).
- 9 Worn transmission rear bushing (Chapter 7).

Rear axle

53 Noise

- 1 Road noise. No corrective procedures available.
- 2 Tire noise. Inspect tires and check tire pressures (Chapter 1).
- 3 Front wheel bearings loose, worn or damaged (Chapter 10).
- 4 Insufficient differential oil (whining noise consistent with vehicle speed changes).

54 Vibration

- 1 See probable causes under *Driveshaft*. Proceed under the guidelines listed for the driveshaft. If the problem persists, check the rear wheel bearings by raising the rear of the car and spinning the wheels by hand. Listen for evidence of rough bearings. Remove and inspect (Chapter 8).

55 Oil leakage

- 1 Pinion oil seal damaged (Chapter 8).
- 2 Axleshaft oil seals damaged (Chapter 8).
- 3 Differential cover leaking. Tighten mounting bolts or replace the gasket as required (Chapter 8).

Brakes

Note: Before assuming that a brake problem exists, make sure that the tires are in good condition and inflated properly (see Chapter 1), that the front end alignment is correct and that the vehicle is not loaded with weight in an unequal manner.

56 Vehicle pulls to one side during braking

- 1 Defective, damaged or oil contaminated disc brake pads on one side. Inspect as described in Chapter 9.
- 2 Excessive wear of brake pad material or disc on one side. Inspect and correct as necessary.
- 3 Loose or disconnected front suspension components. Inspect and tighten all bolts to the specified torque (Chapter 10).
- 4 Defective caliper assembly. Remove caliper and inspect for stuck piston or other damage (Chapter 9).

57 Noise (high-pitched squeal without the brakes applied)

- 1 Disc brake pads worn out. The noise comes from the wear sensor rubbing against the disc (does not apply to all vehicles). Replace pads with new ones immediately (Chapter 9).

58 Excessive brake pedal travel

- 1 Partial brake system failure. Inspect entire system (Chapter 9) and correct as required.
- 2 Insufficient fluid in master cylinder. Check (Chapter 1), add fluid and bleed system if necessary (Chapter 9).
- 3 Rear brakes not adjusting properly. Make a series of starts and stops while the vehicle is in Reverse. If this does not correct the situation, remove drums and inspect self-adjusters (Chapter 9).

59 Brake pedal feels spongy when depressed

- 1 Air in hydraulic lines. Bleed the brake system (Chapter 9).
- 2 Faulty flexible hoses. Inspect all system hoses and lines. Replace parts as necessary.
- 3 Master cylinder mounting bolts/nuts loose.
- 4 Master cylinder defective (Chapter 9).

60 Excessive effort required to stop vehicle

- 1 Power brake booster not operating properly (Chapter 9).
- 2 Excessively worn linings or pads. Inspect and replace if necessary (Chapter 9).
- 3 One or more caliper pistons or wheel cylinders seized or sticking. Inspect and rebuild as required (Chapter 9).
- 4 Brake linings or pads contaminated with oil or grease. Inspect and replace as required (Chapter 9).
- 5 New pads or shoes installed and not yet seated. It will take a while for the new material to seat against the drum or rotor.

61 Pedal travels to the floor with little resistance

- 1 Little or no fluid in the master cylinder reservoir caused by leaking wheel cylinder(s), leaking caliper piston(s), loose, damaged or disconnected brake lines. Inspect entire system and correct as necessary.

62 Brake pedal pulsates during brake application

- 1 Wheel bearings not adjusted properly or in need of replacement (Chapter 1).
- 2 Caliper not sliding properly due to improper installation or obstruction.

tions. Remove and inspect (Chapter 9).

3 Rotor defective. Remove the rotor (Chapter 9) and check for excessive lateral runout and parallelism. Have the rotor resurfaced or replace it with a new one.

63 Parking brake does not hold

1 Mechanical parking brake linkage improperly adjusted. Adjust according to procedure in Chapter 9.

Suspension and steering systems

64 Vehicle pulls to one side

- 1 Tire pressures uneven (Chapter 1).
- 2 Defective tire (Chapter 1).
- 3 Excessive wear in suspension or steering components (Chapter 10).
- 4 Front end in need of alignment.
- 5 Front brakes dragging. Inspect brakes as described in Chapter 9.
- 6 Wheel bearings improperly adjusted (Chapter 10).

65 Shimmy, shake or vibration

- 1 Tire or wheel out-of-balance or out-of-round. Have professionally balanced.
- 2 Loose, worn or out-of-adjustment wheel bearings (Chapters 1 and 10).
- 3 Shock absorbers and/or suspension components worn or damaged (Chapter 10).

66 Excessive pitching and/or rolling around corners or during braking

- 1 Defective shock absorbers. Replace as a set (Chapter 10).
- 2 Broken or weak springs and/or suspension components. Inspect as described in Chapter 10.

67 Excessively stiff steering

- 1 Lack of fluid in power steering fluid reservoir (Chapter 1).
- 2 Incorrect tire pressures (Chapter 1).
- 3 Lack of lubrication at steering joints (Chapter 1).
- 4 Front end out of alignment.

- 5 Air in power steering system (Chapter 10)
- 6 Low tire pressure.

68 Excessive play in steering

- 1 Loose front wheel bearings (Chapter 1).
- 2 Excessive wear in suspension or steering components (Chapter 10).
- 3 Steering gearbox out of adjustment (Chapter 10).

69 Lack of power assistance

- 1 Steering pump drivebelt faulty or not adjusted properly (Chapter 1).
- 2 Fluid level low (Chapter 1).
- 3 Hoses or lines restricted. Inspect and replace parts as necessary.
- 4 Air in power steering system. Bleed system (Chapter 10).

70 Excessive tire wear (not specific to one area)

- 1 Incorrect tire pressures (Chapter 1).
- 2 Tires out of balance. Have professionally balanced.
- 3 Wheels damaged. Inspect and replace as necessary.
- 4 Suspension or steering components excessively worn (Chapter 10).

71 Excessive tire wear on outside edge

- 1 Inflation pressures incorrect (Chapter 1).
- 2 Excessive speed in turns.
- 3 Front end alignment incorrect (excessive toe-in). Have professionally aligned.
- 4 Suspension arm bent or twisted (Chapter 10).

72 Excessive tire wear on inside edge


- 1 Inflation pressures incorrect (Chapter 1).
- 2 Front end alignment incorrect (toe-out). Have professionally aligned.
- 3 Loose or damaged steering components (Chapter 10).

73 Tire tread worn in one place


- 1 Tires out of balance.
- 2 Damaged or buckled wheel. Inspect and replace if necessary.
- 3 Defective tire (Chapter 1).

Contents


Introductory pages		
About this manual	5	
Introduction to the Nissan 300 ZX	5	
General dimensions	8	
Vehicle identification numbers	8	
Buying parts	11	
Maintenance techniques, tools and working facilities	11	
Booster battery (jump) starting	18	
Jacking and towing	19	
Safety first!	20	
Automotive chemicals and lubricants	21	
Conversion factors	22	
Troubleshooting	23	
Chapter 1		1
Tune-up and routine maintenance	30	
Chapter 2 Part A		2A
V6 Engine	63	
Chapter 2 Part B		2B
General engine overhaul procedures	88	
Chapter 3		3
Cooling, heating and air conditioning systems	116	
Chapter 4		4
Fuel and exhaust systems	126	
Chapter 5		5
Engine electrical systems	146	
Chapter 6		6
Emissions control systems	153	
Chapter 7 Part A		7A
Manual transmission	158	
Chapter 7 Part B		7B
Automatic transmission	177	
Chapter 8		8
Clutch and drivetrain	185	
Chapter 9		9
Brakes	204	
Chapter 10		10
Suspension and steering	216	
Chapter 11		11
Body	235	
Chapter 12		12
Chassis electrical system	252	
Wiring diagrams	267	
Index	311	



1985 Nissan 300ZX Turbo



1986 Nissan 300ZX Turbo



1986 Nissan 300ZX 2+2

About this manual

Its purpose

The purpose of this manual is to help you get the best value from your vehicle. It can do so in several ways. It can help you decide what work must be done, even if you choose to have it done by a dealer service department or a repair shop; it provides information and procedures for routine maintenance and servicing; and it offers diagnostic and repair procedures to follow when trouble occurs.

It is hoped that you will use the manual to tackle the work yourself. For many simpler jobs, doing it yourself may be quicker than arranging an appointment to get the vehicle into a shop and making the trips to leave it and pick it up. More importantly, a lot of money can be saved by avoiding the expense the shop must pass on to you to cover its labor and overhead costs. An added benefit is the sense of satisfaction and accomplishment that you feel after having done the job yourself.

Using the manual

The manual is divided into Chapters. Each Chapter is divided into numbered Sections, which are headed in bold type between horizontal

lines. Each Section consists of consecutively numbered paragraphs.

At the beginning of each numbered section you will be referred to any illustrations which apply to the procedures in that section. The reference numbers used in illustration captions pinpoint the pertinent Section and the Step within that section. That is, illustration 3.2 means the illustration refers to Section 3 and Step (or paragraph) 2 within that Section.

Procedures, once described in the text, are not normally repeated. When it is necessary to refer to another Chapter, the reference will be given as Chapter and Section number i.e. Chapter 1/16). Cross references given without use of the word "Chapter" apply to Sections and/or paragraphs in the same Chapter. For example, "see Section 8" means in the same Chapter.

Reference to the left or right side of the vehicle is based on the assumption that one is sitting in the driver's seat, facing forward.

Even though extreme care has been taken during the preparation of this manual, neither the publisher nor the author can accept responsibility for any errors in, or omissions from, the information given.

NOTE

A **Note** provides information necessary to properly complete a procedure or information which will make the steps to be followed easier to understand.

CAUTION

A **Caution** indicates a special procedure or special steps which must be taken in the course of completing the procedure in which the **Caution** is found which are necessary to avoid damage to the assembly being worked on.

WARNING

A **Warning** indicates a special procedure or special steps which must be taken in the course of completing the procedure in which the **Warning** is found which are necessary to avoid injury to the person performing the procedure.

Introduction to the Nissan 300 ZX

The Nissan 300 ZX is a highly redesigned version of the popular Z series cars. While the Z cars were originally designed as sports cars, the ZX series is intended to fit a more luxurious grand touring image.

Some ZX's come with a turbocharged engine, which uses an exhaust gas powered turbine to force more fuel/air mixture into the cylinders for additional power.

All 300 ZX cars utilize a V6, overhead-cam engine with a computer-controlled electronic fuel injection system, and are available with either a 5-speed manual transmission or a 3-speed automatic transmission. Power is transmitted through a rear drive differential carrier which

transmits power to the independently suspended rear wheels by driveaxles which incorporate the use of Constant Velocity (CV) joints to join them to the carrier.

Two body styles are available; the 2-seater version and the roomier, slightly longer 2 + 2 (4-seater) version. Either version can be obtained with the GL or GLL styling/convenience package.

Further information on the various systems and components, as well as complete specifications, can be found in the appropriate individual Chapters.

General dimensions

2-seat model

Overall length	170.7 in
Overall width	66.5 in
Overall height	51.0 in
Wheelbase	91.3 in


2+2 model

Overall length	178.5 in
Overall width	67.9 in
Overall height	51.6 in
Wheelbase	99.2 in

Vehicle identification numbers

Modifications are a continuing and unpublicized process in vehicle manufacturing. Since spare parts manuals and lists are compiled on

a numerical basis, the individual vehicle numbers are essential to correctly identify the component required.



Locations of the various information plates and labels on the 300ZX

Vehicle identification number (VIN)


This very important identification number is located on a plate attached to the top left corner of the dashboard of the vehicle. The VIN also appears on the Vehicle Certificate of Title and Registration. It contains valuable information such as where and when the vehicle was manufactured, the model year and the body style. Also, the VIN label contains information about the way in which the vehicle is equipped.

This plate is especially useful for matching the color and type of paint during repair work.

Engine identification numbers

The engine identification number is located on a pad at the rear of the cylinder block.

Prefix and suffix designations





300ZX vehicle identification code chart

NISSAN MOTOR CO., LTD. JAPAN			
型式	TYPE TIPO	1	
CHASSIS NO. NO. DE CHASIS		2	
MODEL MODELO		3	
○ カラー COLOR TRIM トリム COLOR GUARNICION		4	5
エンジン ENGINE ジン MOTOR		6	7
ミッション TRANS. AXLE アクスル TRANS. EJE		8	9
	工場 PLANT PLANTA		
日産自動車株式会社		MADE IN JAPAN	

- 1 Type
- 2 Vehicle identification number (Chassis number)
- 3 Model
- 4 Body color code
- 5 Trim color code
- 6 Engine model
- 7 Engine displacement
- 8 Transmission model
- 9 Axle model

300ZX vehicle identification number (VIN) plate



Location of the engine serial number